



Question/Issue

After selecting the "Reset" button in Settings / Customize, my toolbars appear to be gone. How can I fix this?

Answer/Solution


When using the "Reset" button in Settings / Customized, your toolbars may become scrambled and an MTB error message may appear:





If this does happen:

- Shut down Mastercam.
- Browse to the \config\ directory of your Mastercam installation



Remove purged portion of file name.

Restart Mastercam Should be resolved.