

Question/Issue

How do I set tapping function in drilling cycle?

Rigid Tapping

This is machine dependent in regards to how the machine control deals with standard tapping G99 G84, normally done with a compression extension holder and Rigid tapping in some machine controls a pre-call of M29 is output in the code.

